


Figure 2



00729503 121900






Figure 3c

Figure 3b




Figure 3d

[illegible]

The diagram illustrates the layout of the 'GOLF' mode screen. The screen is divided into several sections with the following labels and line numbers:

- 24**: DG PLAYER (Top left)
- 67**: 3 HOLE (Top center)
- 69**: 5 MIN TO NEXT T (Top center)
- 30**: MODE: PLAY GOLF (Bottom left)
- 0**: YRDS TO GREEN (Top right)
- 68**: P (Top right)
- 20**: NEXT CLUB (Top right)
- 2**: STROKES ON HOLE (Top right)
- 70**: (Top right)
- 24**: CURSOR (Bottom center)
- 24**: ENTER STROKE (Bottom right)

Figure 5

RESORT HILLS COUNTRY CLUB


DAN E. GOLFER

AUGUST 15, 2000

HOLE	1	2	3	4	5	6	7	8	9	OUT
YARDS	350	360	250	425	525	425	555	210	450	3,550
PAR	4	4	3	4	5	4	5	3	4	36
SCORE	5	5	4	6	5	5	6	4	4	44

HOLE	10	11	12	13	14	15	16	17	18	IN
YARDS	435	530	440	350	365	190	405	230	600	3,545
PAR	4	5	4	4	4	3	4	3	5	36
SCORE	4	7	5	4	4	3	5	4	6	42

X MARKS LOCATION OF STROKES



00739503-121900